NILAN Compact P Installer's trolley instructions.

Step 1 Remove bottom door panels



Step 2 Screw in feet to maximise gripping effect



Step 3 Lock wheels



Step 4 Tilt unit and hook locked wheels under cylinder side



Step 5 Insert rubber pad before lowering unit



Step 6 Repeat steps 4&5 pushing against the locked wheels



Step 7 Unlock wheels and move to final location



- To take unit off the trolley follow steps in reverse.
- Do NOT use trolley when cylinder has water in it.
- Do NOT use on sloped ground where you may loose control of trolley.
- Do NOT use trolley without the rubber pads provided.

Width 580mm Height 155mm Depth 255mm

Weight 10kg each (Shipping weight 20kg)

Purchase in online shop at www.nilan.green

